


Switched Fused Distribution Board with Fuse and Fault Indicator

Features:


- Fuse for overload protection
- Fault Indicator Lamp
- Switch for Local Disconnect
- Power Indicator Lamp
- 12x 2-pole 6-amp terminals
- 1x 2-pole 10-amp terminal

Be certain your power supply shows the following symbols indicating DC power, with Tip Positive polarity.

DC 



Terminal Polarity is staggered for convenience of connecting multiple power lines to a flush mounting surface.



If the power supply provides a Tip Positive Polarity, then the illustration above will show the proper polarity of the terminals from Left to right.